


Key-Board



[Frequency list 400 channels mode](#)

1	2	3	4	5	6	7	8	
0	0	1	0	0	0	0	0	HAM-Radio - 28.000MHz to 29.700MHz
0	0	1	0	0	0	1	0	HAM-Radio - 25.000MHz to 29.700MHz
0	0	0	0	1	0	1	1	400 Ch. FM and AM
0	0	0	0	1	0	0	1	400 Ch. FM
0	0	0	0	1	0	0	0	200 Ch. FM and AM
0	0	0	0	0	1	1	1	200 Ch. FM
0	0	0	0	0	1	1	0	12 Ch. AM 1 Watt and 80 Ch. FM 4 Watt
0	0	0	0	0	0	1	0	40 Ch. AM and FM
0	0	0	0	0	0	0	0	40 Ch. FM (CEPT)